



## CLAW INSTRUCTIONS

Read these instructions completely before you start. If you don't understand these instructions, please call 800-453-1192 for assistance. Failure to comply with all instructions may result in serious injury.

### TO ENGAGE

1. Turn cable hooks out to the forward position.
2. Attach the lanyard\* to the back side of the base section of the ladder, by pulling it down and looping it around the 4th or 5th rung.
3. While maintaining a firm grip on the ladder, extend the ladder to just above the cable line.  
(The Claw will be in the down position, see picture 1.)
4. Slowly lower the ladder onto the strand, as you do the strand will engage the Claw and the hooks.  
(The Claw pivots up and secures the top of the ladder, see picture 2.)
5. Adjust the angle of the ladder until the rung locks are engaged, the rungs are even, and the feet are on solid ground. Set the angle of the ladder as close to 75.5 degrees as possible.
6. Attach your lanyard to your harness.
7. Climb the ladder.



### TO DISENGAGE

1. Climb down the ladder.
2. Attach the lanyard to the back side of the base section of the ladder, by pulling it down and looping it around the 4th or 5th rung.
3. Bring in the base of the ladder, so the ladder is nearly straight up and down.
4. Tip the top of the ladder back to clear the strand and then lower the ladder to the storage position.
5. Return the cable hooks to the storage position.
6. Do not store the ladder with lanyard extended.
7. Follow manufacturer's recommendations for use and care of lanyard and harness.



\*Lanyard and Harness are not included with the ladder.

Little Giant Ladder Systems  
1198 N. Spring Creek Place  
Springville, UT 84663

800-453-1192

©2013 Little Giant Ladder Systems 58177 v3 6.13