



**CLIMB ON**

# FULL FOOT REPLACEMENT

READ THESE INSTRUCTIONS COMPLETELY BEFORE YOU START. IF YOU DON'T UNDERSTAND THESE INSTRUCTIONS, PLEASE CALL 800-453-1192 FOR ASSISTANCE

Procedure for replacing the feet on Little Giant Ladder Systems **MICROBURST** ladders.

1. Failure to comply with all instructions may result in serious injury.
2. Make sure this kit is compatible with your ladder. If you have any questions concerning the use of this kit on Little Giant Ladder Systems products, call 800-453-1192 for assistance.
3. Before installing this kit, identify all kit components. If any components are missing or damaged, please contact Customer Care. Do not substitute any components.
4. Inspect the ladder before installing this kit. Repair or replace any damaged or missing ladder parts before using the ladder. Use only Little Giant Ladder Systems repair or replacement parts. If you are unable to repair it, discard the ladder.

## COMPONENTS IN KIT

## TOOLS NEEDED


	(1) LEFT FRONT FOOT & (1) RIGHT FRONT FOOT		(2) 3/8" WRENCHES		CHISEL	
	(1) LEFT REAR FOOT & (1) RIGHT REAR FOOT				3/16" PUNCH	
			RIVET GUN		3/16" DRILL BIT	
	(4) POP RIVETS				HAMMER	
	(4) HEX HEAD BOLTS				DRILL	
	(4) CENTER LOCK NUT		(4) WASHERS			

NOTE: IF ANY OTHER PART OF THE LADDER IS DAMAGED BEFORE OR DURING THE PROCESS OF INSTALLING AND/OR REPAIRING, DISCARD THE LADDER OR CONTACT CUSTOMER CARE FOR INSTRUCTIONS.


**DO NOT USE A DAMAGED LADDER!**




1. Identify the foot that needs to be replaced.




2. Using a drill with a 3/16" drill bit, drill through just the head of the rivet. (As shown in the illustration).




3. Using a hammer and chisel, tap off the top of the rivet shank.



4. Using a 3/16" punch, completely remove the remaining rivet.




5. Remove the (existing) foot and discard.




6. Insert the (new) foot.



# \*\*\*STEPS 7-8 ARE IF YOU WANT TO SET THE FEET WITH A RIVET GUN\*\*\*




7. Insert pop rivet (included in kit), into existing hole (as shown in the illustration).



8. Once set, the rivet will expand and hold (new) foot into place.


# \*\*\*STEPS 9-10 ARE IF YOU WANT TO SET THE FEET NUTS AND BOLTS\*\*\*



9. Insert hex head bolt, washer and center lock nut into (existing) hole, as shown in the illustration.



10. Set with (2) 3/8" wrenches.



11. Repeat steps 1-10 on remaining 3 feet.



12. Once all the steps are completed, make sure that it is completely stable before use.